



Pos.	Teil-Nr.:	Bezeichnung	Pos.	Teil-Nr.:	Bezeichnung
1	19016131	Spannmutter	14	19016144	Ventildeckel
2	19016132	Spannzange (3 mm)	15	19016145	Gehäuse
3	19016133	Spannzangenhülse	16	19016146	Stöpsel
4	19016134	Frontabschluss	17	19016147	Innenventil
5	19016135	Kugellager (2)	18	19016148	Zylinderstift
6	19016136	Zentrierring	19	19016149	Drehventil
7	19016137	Druckscheibe	20	19016150	O-Ring
8	19016138	Zylinder	21	19016151	O-Ring (2)
9	19016139	Rotor	22	19016152	Schraube
10	19016140	Rotorblatt (4)	23	19016153	Endhalter
11	19016141	Zylinderstift	24	19016111	Schlauch
12	19016142	Lagerhalter	25	19016155	Abluftschlauch
13	19016143	Kugellager	26	19016156	Gabel-Spannschlüssel (2)